


➔ SG

## Installation



**Connection to KCtr**  
E5: Gas/Fire Sensors

**See KCtr diagram**  
Installation of Gas or Fire sensors  
CONTACT Type

**Sensor fitting**  
Following the density variations of different commercial gases, the sensor must be installed up to 30cm from the floor when the risk is from Butane Gas and Propane Gas and 30cm from the ceiling when the risk is from Natural Gas or City Gas.